

HOW TO APPLY CUTEK® WOOD STRIPPER



A SIMPLE STEP-BY-STEP GUIDE

1 PROTECT AND TEST

Protect adjacent surfaces, vegetation, vehicles and pedestrian areas. Test a small area first to determine the required working time and amount of product.

2 APPLY TO DRY WOOD

Stir or shake the product thoroughly. Apply CUTEK® Wood Stripper evenly to dry wood using a brush, roller or paint pad, working it into the grain.

3 KEEP ACTIVE

Allow approximately 30–60 minutes for the coating to soften. Keep the area wet and active by applying more product or agitating it with your applicator.

4 TEST THE COATING

Periodically test with a paint scraper. When the old coating lifts cleanly, the surface is ready to rinse. Thick or multiple coating layers may require another application.

5 PRESSURE RINSE

Rinse thoroughly using a pressure washer at approximately 750 psi with a fan jet. Work from the lowest point upward, using even strokes in the direction of the grain.



Always rinse from the bottom upward. Starting at the top can allow product farther down the surface to become sticky and more difficult to remove. **Use CUTEK® Wood Reviver after the wood is stripped.**

- ✓ **SURFACES BECOME SLIPPERY:** Do not walk on the treated area until the product is removed.
- ✓ **A GARDEN HOSE IS NOT SUFFICIENT:** Pressure rinsing is required for thorough removal.
- ✓ **ALWAYS USE WOOD REVIVER:** This removes residue and restores the wood after stripping

WATCH OUR VIDEO TUTORIAL

Use this step-by-step video as an additional resource to guide you through using CUTEK® Wood Stripper.

Follow the practical demonstration and expert tips to safely soften, remove and rinse away existing wood coatings.

Complete removal allows CUTEK® Wood Reviver and CUTEK® Extreme to work effectively as the next stages of the restoration system.

