

HOW TO APPLY CUTEK® WOOD STRIPPER



A SIMPLE STEP-BY-STEP GUIDE

1 PROTECT AND TEST

Protect adjacent surfaces, vegetation, vehicles and pedestrian areas. Test a small area first to determine the required working time and amount of product.

2 APPLY TO DRY WOOD

Stir or shake the product thoroughly. Apply CUTEK® Wood Stripper evenly to dry wood using a brush, roller or paint pad, working it into the grain.

3 KEEP ACTIVE

Allow approximately 30–60 minutes for the coating to soften. Keep the area active by applying more CUTEK® Wood Stripper or agitating with your applicator. Do not add water during this stage. Only rinse once the coating is ready to be removed.

4 TEST THE COATING

Periodically test the old coating with a paint scraper to check if it is lifting cleanly. Once the coating can be easily removed, the surface is ready to rinse. Thick or multiple coating layers may require another application.

5 PRESSURE RINSE

Rinse thoroughly using a pressure washer at approximately 750 psi with a fan spray. Work from the lowest point upward, using even strokes in the direction of the grain.



Always rinse from the bottom upward. Starting at the top can allow product farther down the surface to become sticky and more difficult to remove. **Use CUTEK® Wood Reviver after the wood is stripped.**

- ✓ **SURFACES BECOME SLIPPERY:** Do not walk on the treated area until the product is removed.
- ✓ **A GARDEN HOSE IS NOT SUFFICIENT:** Pressure rinsing is required for thorough removal.
- ✓ **THEN CUTEK® WOOD REVIVER:** This removes Wood Stripper residue and restores the wood after stripping

WATCH OUR VIDEO TUTORIAL

Use this step-by-step video as an additional resource to guide you through using CUTEK® Wood Stripper.

Follow the practical demonstration and expert tips to safely soften, remove and rinse away existing wood coatings.

Complete removal allows CUTEK® Wood Reviver and CUTEK® Extreme to work effectively as the next stages of the restoration system.

