CUTEK® WOOD REVIVER

PROFESSIONAL WOOD RESTORATION



CUTEK® Wood Reviver (formerly CUTEK® Proclean) is a powerful wood cleaning agent that restores stained, weathered and gray wood back to its original appearance.

CUTEK® Wood Reviver is effective in removing stubborn stains caused by tannins, water, iron, resins, mold and fungus. It also removes the common invisible glaze (mill glaze) to prepare newly sawn or machined wood for coating.

CUTEK® Wood Reviver is a one step brightener and cleaner of many types of stains and will brighten, clean and restore wood to look like new, ready for coating with CUTEK® Extreme.

WHY CUTEK® WOOD REVIVER?

- **Powerfully restores wood** – brings weathered, grayed/silvered wood back to its original appearance.
- **Removes stubborn stains** – such as iron stains, water marks, tannins, resins, mold and fungus.
- **Prepares new wood for coating** – removes common invisible glaze ('mill glaze') from newly sawn wood or machined wood.

CUTEK® WOOD REVIVER



DIRECTIONS FOR USE

WHAT YOU WILL NEED



Roller, broom or low-pressure garden sprayer



Bucket



Pressure washer



Drop sheets and tarps



Safety equipment

COVERAGE

Spreading rate is approximately 200-300 ft^2/ US gal

IMPORTANT: These figures represent typical averages for common decking and cladding species and are to be used as a guideline only.

IMPORTANT INFORMATION

CUTEK® Wood Reviver is a powerful wood cleaning agent that restores stained, weathered and gray wood back to its original appearance.

It is important for the user to determine the suitability of CUTEK® Wood Reviver for its intended application. Always use undiluted. Do not add water.

ALWAYS test product on a small test area, prior to applying to any large sections. As the species and condition of wood can vary significantly, testing will enable you to accurately estimate the working time, and amount of CUTEK® Wood Reviver required to complete your project. It will also enable you to perfect the cleaning technique.

NOTE: CUTEK® Wood Reviver will not remove paint and wood coatings from your wood. To remove wood coatings and paints such as latex paints, stains, varnishes, linseed oils, acrylics and other film forming coatings, use CUTEK® Wood Stripper.

CUTEK® WOOD REVIVER



PRECAUTIONS

Before you begin to Prepare and Protect your wood, note the hazards and precautions on the product label and ensure that you have obtained and know how to use the correct safety equipment. CUTEK® Wood Reviver is a hazardous chemical. It is important to refer to the health and safety considerations listed in the Safety Data Sheet (SDS) prior to starting your project. When using CUTEK® Wood Reviver, all adjacent surfaces and vegetation must be adequately protected.

It is also important to be aware of the potential for wind drift into areas with cars or pedestrian traffic when rinsing. Water flush all equipment, vegetation, paths, concrete, asphalt and other adjacent surfaces before and after contact.

DO NOT SWALLOW

CUTEK® Wood Reviver will make surfaces slippery, DO NOT walk on the surface until it is dry.

A full list of precautions and the SDS is available at cutekwoodsolutions.com

STEP 1 ▸ PREPARE

APPLICATION: Wet your wood prior to applying CUTEK® Wood Reviver. Leave Wood Reviver on the wood for 1–4 hours, depending on the severity of staining or discoloration. If needed, it can remain on the wood for up to 24 hours, although longer periods may make rinsing more difficult. It may be necessary to scrub stubborn stains moderately with a stiff fibre brush.

REMOVAL: Rinse off thoroughly, using a pressure washer set to approximately 50 bar (750 p.s.i.) with a wide fan jet pattern (1.5" – 2"). Keep an operating distance of at least 4" from the wood. REMOVAL WITH A GARDEN HOSE IS NOT SUFFICIENT.

CAUTION must be used to avoid damage to the wood fiber and 'furring up'. Adjust your cleaning process by reducing the pressure or your operating distance from the wood. DO NOT use "turbojets" on wood.

Rinse from the highest point and work down methodically using long even strokes in the direction of the grain, until there is minimal to no sudsing. The longer that CUTEK® Wood Reviver is left on the wood, the greater the rinse time required.

CLEAN-UP: Equipment may be cleaned with water. Ensure wash water is disposed in accordance with local regulations.

STEP 2 ▸ PROTECT

CUTEK® WOOD REVIVER



Following the rejuvenation of your wood, complete the restoration process by protecting your wood with CUTEK® Extreme after ensuring the rejuvenated wood is completely dry with a moisture content less than 17% (this typically takes 2-3 days, however, this time can vary depending on ventilation and weather exposure).

Designed for and proven to work in the harshest of American environments, CUTEK® Extreme penetrates and diffuses deeply into the wood core to protect against liquid and gas phase moisture and extend service life.



CUTEK® Extreme

High performance penetrating oil-based wood stabilizer with a unique self-healing effect that highlights the natural beauty of wood and controls moisture to improve dimensional stability and minimize cupping, warping and splitting.

Maintenance with CUTEK® Extreme is simple, easy and cost effective. Simply clean and recoat – no need to sand or strip.

N[illegible]our wood with CUTEK® Extreme after cleaning will result in water damage and a faster weathering/graying process when exposed to the weather.

For other hints, pro-tips and videos on how to use CUTEK® Prepare and Protect products, visit the CUTEK® website: cutekstain.com